

K14070-1 5M (50162)

| | | | |
|-----------------------|--------------------|---------------------|--|
| ASSEMBLY PAGE NAME | | Machine Assembly | |
| CODE NO.: | FIGURE NO.: | A | |
| 50162 | LF33S Hand Amptrol | 1 | |
| | | | |

| Item | Description | Part Number | QTY | 1 | 2 |
|------|--------------------------------|------------------|-----|---|---|
| 1 | COVER ASSEMBLY | R-3019-164-1/02R | 1 | X | |
| 2 | BASE | R-1019-037-1/02R | 1 | X | |
| 3 | KNOB | 9ET10491R | 2 | X | |
| 4 | TRIMMING POTENTIOMETER | 1158-113-304R | 2 | X | |
| 5 | CABLE | R-5041-027-1R | 1 | X | |
| 6 | LABEL | R-7040-302-1AR | 1 | X | |
| 7 | AMPHENOL PLUG MALE (6- PIN) | 1158-641-104R | 1 | X | |
| 8 | KLAMP | 1158-641-108R | 1 | X | |
| 9 | STUFFING BOX | 1131-154-003R | 1 | X | |

